







Zone		Zone Definition	ATEX Category	ATEX Equipment Marking	IEC Ex EPL
Gas	Zone 0	A place where explosive atmosphere is present contentiously or for a long period.	Category 1	 II 1G	Ga
	Zone 1	A place where explosive atmosphere is likely to occur occasionally in normal operation.	Category 1, 2	 II 2G	Gb
	Zone 2	A place where explosive atmosphere is likely to occur infrequently or for a short period.	Category 1, 2, 3	 II 3G	Gc
Dust	Zone 20	A place where explosive atmosphere is present contentiously or for a long period.	Category 1	 II 1D	Da
	Zone 21	A place where explosive atmosphere is likely to occur occasionally in normal operation.	Category 1, 2	 II 2D	Db
	Zone 22	A place where explosive atmosphere is likely to occur infrequently or for a short period.	Category 1, 2, 3	 II 3D	Dc

ATEX ZONES

